LED Wall Scone



START FROM HERE

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area
- Wear gloves at all time during this installation
- · Read instructions carefully before you start assembly
- · Keep this installation sheet for future reference

Technical Support: 1-855-855-8926

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required.
- 1. Remove the fixture from its original packaging. Remove the mounting bracket(1c) from the canopy(2b) by unscrew two screws (2a). Attach this mounting bracket (1c) to the electrical junction box (1a), by using screws (1d) provided in the hardware package.
- 2. Attach the canopy to the mounting bracket, which is attached to the electrical junction box on the wall. First connect all wires correctly G ground to ground, N neutral wire (white to white), L live wire (black to black) with provided marettes (1b) from the hardware package. Now place the canopy (2b) onto the mounting bracket (1c). As you move the canopy, align the top & bottom holes to the holes on the mounting bracket (1c). Secure the canopy (2b) by using the screws (2a) provided.
- $oldsymbol{3}$. You have now completed the installation of your fixture, enjoy.



