

ASSEMBLY INSTRUCTION



Sunpan Item No: **107162**

Sunpan Product Name: **AKITA BED - KING**

Please visit our website www.sunpan.com for more great products.

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com

PARTS LIST



Before you begin, please layout all parts and ensure you have the correct count.

NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Headboard	1	
B	Footboard	1	
C	Side Rail	2	
D	Support Rail	2	
E	Center Leg	4	
F	Slats	1	
G	Leg	4	
H	Bolts (Ø8*25mm)	16	

I	Lock Washers (Ø8)	16	
J	Washers (Ø8)	16	
K	Bolts (Ø6*40mm)	16	
L	Lock Washers (Ø6)	16	
M	Washers (Ø6)	16	
N	Allen Key	1	
O	Screw	24	

ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	<p>Attach Side Rail (C) to Headboard (A), Footboard (B) by using Allen Key (N) to fix Bolt (H), Lock Washer (I) & Washer (J).</p>	
2	<p>Attach Leg (G) to Bed by using Allen Key (N) to fix Bolt (K), Lock Washer (L) & Washer (M).</p>	
3	<p>Attach Center Leg (E) to Support Rail (D).</p>	
4	<p>Attach Support Rail, Center Leg to Bed.</p>	

5	Attach Slats (F) to Bed by using Phillips Screwdriver to fix Screw (O).	
6	Assembly completed.	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.
 Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:
 Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.
 Excessive exposure to sunlight may cause fading.
 Excessive temperature and humidity or cold may cause cracking or splitting.
 Dust with a clean, damp, lint free cloth.
 Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.