

ASSEMBLY INSTRUCTION

SUNPAN


Sunpan Product Name: CASETTE BED

Please visit our website **www.sunpan.com** for more great products

For assembly questions please call 1-800-787-1019 (or +1-416-736-0094) outside North America or email to info@sunpan.com

PARTS LIST Before you begin, please layout all parts and ensure you have the correct count.				
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION	
A	Headboard	1		
В	Footboard	1		
С	Rail	2		
D	Top Stretcher	2		
E	Slat	1		
F	Slat Support	2		

G	Bolt (M8X20mm)	12				
н	Bolt(M8X50mm)	8				
I	Screw (M4X40)	24	(X) DIIIIIIID>			
J	Lock Washer	20	Ð			
К	Flat Washer(M8X16mm)	20				
L	Allen Key(4mm)	1				
ASSEMBLY INSTRUCTIONS						
STEPS	DESCRIPTION	ILLUSTRATION				
1	Please assemble this bed in your desired room or place. With the help of another person, Stand the Headboard(A) and the footboard(B) up to begin assembling. Attach the 2 Top Stretchers (D) to the					



4	Place the Slats(E) onto the top of Slat Support Stretcher(F) and wood supports attached to inner sides of Rails(C). Be sure all slats are placed evenly before attaching each Slats(E) to Rails(C) by using Screws(I). Please Tighten all Screws(I).	
5	Assembly completed.	

ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step. Place a protective pad or piece of cardboard on the floor while assembling your item on top of it. Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list. Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement. Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster. Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.